


ASSEMBLY

- ❶ bottom
- ❷ Back board
- ❸ left board
- ❹ right board
- ❺ latch
- ❻ riser of seat
- ❼ bottom conjunction heads
- ❽ upper board of seat
- ❾ back heaters and hanging screws
- ❿ backrest
- ⓫ Roof and four screws
- ⓬ front board
- ⓭ conjunction heads
- ⓮ front heaters and hanging screws
- ⓯ Handleand screws
- ⓰ conjunction Heads of speaker and lamp
- ⓱ eave and Four Screws
- ⓲ CD player
- ⓳ Electronic box



ASSEMBLY STEP

